



Utility Cart

Assembly and User Manual
ITEM: BCH-902340

| Assembly Instructions



Step 1. Remove folded cart from packaging.

Step 2. Take 4 cart wheels out of the pouch. Attach the wheel with the locking mechanism at rear of the cart with lock facing outwards. Attach 3 remaining wheels to the cart.

Step 3. Push the wheels into the holes until it snaps into place.

Step 4. Now you are ready to open your cart and use it.



| How to Open Cart



Step 1. Place cart down with the wheels to the ground and pull up the cart handle.

Step 2. Keep pulling up until the cart unfolds and is standing on all 4 wheels.

Step 3. Push down the front of the cart until the front pops open.

Step 4. Now you can place the liner inside the cart (has velcro to attach) and you are ready to use your cart.

| How to Close Cart



Step 1. Place cart down with the wheels to the ground.

Step 2. Push the cart forward onto the front until it bends.

Step 3. Push down the handle of the cart as the cart collapses close.

Step 4. Your cart is folded and ready for easy storage.

If you have any questions or problems please **do not return** to the place of purchase. Contact our customer service department toll free at **1-855-880-7205** or email us at **customerservice@atleisure.com**

How to Lock & Unlock Wheel |



To Lock: Turn lock so the knob is level or horizontal to the ground.



To Unlock: Turn lock so the knob is in upright position or vertical to the ground.



Turn it around 360° to lock or unlock.

Warranty & Warnings |

90-DAY WARRANTY

This product is covered under a manufacturer's 90-day warranty from date of purchase against defects in materials and workmanship. This warranty does not cover damage due to neglect, abuse or weather related damage. For full warranty disclosure, email us at customerservice@atleisure.com.

WARNINGS

Loading capacity is 100 lbs.

Please do not place anything in the cart exceeding 100 lbs.

Please do not place children/babies in the cart.

CARE INSTRUCTIONS:

Simply clean with cloth and mild detergent.

Do not machine wash.

Do not iron.

Air dry thoroughly before storing for extended periods of time.

atleisure[®]
create your escape

www.atleisure.com
ATLANTA, GEORGIA
Customer Service Toll Free 1-855-880-7205
Monday through Friday from 8:00am-5:00pm
(Eastern Time)