




Concrete Umbrella Stand Assembly and User Manual

ITEM: UMB-939100







M27543

| Package Contents 2.



The schematics in this manual are for assembly and operation illustration only. They may differ from the stand's actual appearance.

PICTURE



DESCRIPTION

Umbrella Stand Base (with connected bolt and plastic nut)

Decorative Ring

Umbrella Stand Tube (with Nut)

Locking Bolt

Ring Adapter (Large: 38mm, Medium: 35mm, Small: 30mm)

Shim

QTY(PC)

1

1

1

1

1


If you have any questions, problems or need additional parts please **do not return** to the place of purchase. Contact our customer service department toll free at **1-855-880-7205** or email us at **customerservice@atleisure.com**

3. Instructions Of Set-Up & Operation |

Step 1. Carefully open the carton box on a flat surface. Reference Fig 1 to assemble the stand. Fasten the Plastic Nut (C) clockwise to the Connected Bolt (B) until secure. They should stick out about 0.59 - 0.79 inches.

Step 2. Insert the Shim (I) through the Connect Bolt (B). Place the Decorative Ring (D) onto the Umbrella Stand Base (A) through the Connected Bolt (B).

Step 3. Attach the Umbrella Stand Tube (E) to the Umbrella Stand Base (A) by screwing it to the Connected Bolt (B); make sure it secures the bolt.



| Instructions Of Set-Up & Operation (cont'd) 4.

Step 4. Fasten the Locking Bolt (G) to the small Nut (F).

Step 5. There are 3 ring adapters (H) that have been placed inside the umbrella stand tube (E). All three adapters must be pulled out to accommodate a larger size pole. The first two adapters are easy to pull out. The third adapter fits tight to the umbrella stand tube and may require more force to remove. Select a suitable adapter according to the size pole as shown in the list in Fig 2. When using the small ring adapter, the medium one and the larger one should be used with the small adapter. When using the medium ring adaptor, the large one should be used with the medium adapter.




Fig. 2

When ready to use, tighten the Locking Bolt (G) to hold the umbrella pole in place. The Locking Bolt (G) should press on the surface of the Ring Adapter (H) in order to avoid damaging the surface of the umbrella pole.

To prevent the stand tube from eroding, **do not** use acids to clean it.

Please note this item is **heavy**. Take care when handling.







90-DAY WARRANTY

This product is covered under a manufacturer's 90-day warranty from date of purchase against defects in materials and workmanship. This warranty does not cover damage due to neglect, abuse or weather related damage. For full warranty disclosure, email us at **customerservice@atleisure.com**.

HOW TO FILE A CLAIM

If you are within your warranty, to file a claim you must have your receipt and pictures of your damaged product. Email information to ATLeisure at **customerservice@atleisure.com**.

7. Replacement Parts |

DESCRIPTION	PICTURE	RE-ORDER NO.
Base		BSE-ABSE-GRY
Connected Bolt		BSE-BBLT-SLVR
Plastic Nut		BSE-CPN-SLVR
Decorative Ring		BSE-DDR-SLVR
Tube		BSE-ETBE-BLK
Locking Bolt		BSE-GLB-BLK
Ring Adapter		BSE-HADPTL-BLK BSE-HADPTM-BLK BSE-HADPTS-BLK
Shim		BSE-ISHM-SLVR



 create your escape

www.atleisure.com
 ATLANTA, GEORGIA
Customer Service Toll Free 1-855-880-7205
 Monday through Friday from 8:00am-5:00pm
 (Eastern Time)